LUCAS H 52 WIRING SYSTEM
BEFORE DETACHING SWITCH FROM LAMP
BODY, DISCONNECT + TERMINAL AT BATTERY
TO DYNAMO FIELD TERMINAL
F
TO TAIL LAMP
EARTHED TO FRAME
E
+B
TO BATTERY + TERMINAL
T
H
+D
TO DYNAMO + TERMINAL
L
3 CORE
N
TO HANDLE BAR SWITCH